















26.901.165
 26.901.165 10
 26.901.165 12
 26.901.165 18
 26.901.165 20
 26.901.165 23
 26.901.165 25
 26.901.165 30
 26.901.165 3H



ASSEMBLARE SU 29.1903.9 CON LOXEAL 58-10
 ASSEMBLE ON 29.1903.9 WITH LOXEAL 58-10



ASSEMBLATO SULLA LANCIA CON LOXEAL 56-03
 ASSEMBLE ON SPRAY GUN WITH LOXEAL 56-03



ASSEMBLATO SU 26.1502.45
 ASSEMBLED ON 26.1502.45

COME SI ORDINA/HOW TO ORDER
 Solo kit tenuta Seal kit only **23.302.12**

COME SI ORDINA/HOW TO ORDER
 Kit ricambio Spare parts kit **26.302.6**